


## Structure of microfiche



1. Read from left to right
2. Title of microfiche (appears on each coordinate)


<b>E16</b>	Product/component/test step
	Vehicle/engine

Coordinate


3. Limits of section



Beginning



Mid-section



End



One-page section

4. References to relevant test steps in test specifications; coordinate e.g. C6

**C6**

**A1**

Trouble-shooting program



## 1. Special features

Revised test instructions for

Car Alarm I, II

Plus 3 (wheel-protection system),

Plus 4 (passenger-compartment protection)

12 V and 24 V

Two-Wheeled Vehicle Alarm

Boat Alarm

High-voltage arrows on the circuit diagrams  
mean: Caution, high-voltage, 400 V ... 25 kV.



## 2. Test specifications

### Car Alarm I

Battery voltage	10 ... 13 V
Priming	25 ... 45 sec.
Alarm time	25 ... 30 sec.
Response time	5 ... 8 sec.

### Car Alarm II

Battery voltage	10 ... 13 V
Voltage between terminal E and vehicle ground	
Alarm switched on	3.2 ... 4.5 V
Alarm switched off	4.8 ... 6.5 V
Priming	immediate
Alarm time	20 ... 30 sec.
Response time	immediate

### Car Alarm Plus 3

Battery voltage	9 ... 13 V
Tilt sensor adjustment time	approx. 45 ... 55 sec.
Response time	approx. 1 ... 2 sec.



## Test specifications (continued)

### Car Alarm Plus 4

Battery voltage	10 ... 13 V
Priming with Car Alarm I	25 ... 45 sec.
Priming with Car Alarm II	immediate
Alarm time	20 ... 30 sec.
Response time with Car Alarm I	5 ... 8 sec.
Response time with Car Alarm II	immediate

### Two-Wheeled Vehicle Alarm

Battery voltage (vehicle electrical system) (own battery)	9 ... 13 V 9 V accumulator
Priming	immediate
Alarm time	20 ... 30 sec.
Response time	immediate

### Boat Alarm

Battery voltage	8 ... 13 V
Priming	10 ... 20 sec.
Alarm duration	20 ... 30 sec.
Alarm delay	5 ... 8 sec.



### 3. Necessary test equipment and tools

Electrics tester	ETE 014.00	0 684 101 400
------------------	------------	---------------

Stopwatch		commercially available
-----------	--	---------------------------

**A5**

Test equipment, tools  
Alarm systems



#### 4. Possible circuit diagrams for Car Alarm I, II, Plus 3, Plus 4, two-wheeled vehicle alarm, Boat Alarm

The circuit diagrams shown on the following Coordinates may be of assistance to the experienced expert when trouble-shooting.

The Coordinates show formerly used circuits and new circuits.

They are arranged in the following order:

Car Alarm I

Car Alarm II, 12 and 24 V

Car Alarm Plus 3 (wheel protection)

Car Alarm Plus 4 (passenger-compartment protection)


Two-wheeled vehicle alarm

Boat Alarm

Where high-voltage arrows appear on circuit diagrams, e.g. at ignition coils, this means:

C A U T I O N     400 v - 25 Kv!






- |                              |  |
|------------------------------|--|
| 1 = Alarm relay              | 5 = Fuse box   |
| 2 = Alarm switch             | (8 A fuse)   |
| 3 = Alarm horn               | 6 = Ignition coil  |
| 4 = Ignition/starting switch | 12 = Relay (12 V change-over contact, here as normally-open contact) |

#### 4.1 Circuit diagrams - Car Alarm I

##### 4.1.1 Basic circuit with ignition immobilization (Car Alarm I) with separate alarm horn

Alarm switch 2 switches "negative" (-) to alarm relay 1.

In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.



- 1 = Alarm relay
- 2 = Alarm switch
- 3a = Switch for standard horn
- 3b = Standard horn
- 4 = Ignition/starting switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 12 = Relay (12 V, change-over contact, here as normally-open contact)


#### 4.1.2 Basic circuit with ignition immobilization (Car Alarm I) with standard horn

Horn switch switches "negative".

Alarm switch (2) switches "negative" (-) to alarm relay.


In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.





Horn switch switches "positive".  
Alarm switch 2 switches "negative" (-) to alarm relay 1.






- 1 = Alarm relay
- 2 = Alarm switch
- 3a = Switch for standard horn
- 3b = Standard horn
- 4 = Ignition/starting switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 12 = Relay (12 V, change-over contact, here as normally-open contact).

#### 4.1.5 Basic circuit with ignition immobilization (Car Alarm I) with standard horn

Alarm switch (2) switches "positive" (+) to alarm relay.  
Horn switch switches "negative".

In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.




- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition/starting switch

- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 12 = Relay (12 V, change-over contact, here as normally-open contact)

#### 4.1.6 Basic circuit with ignition immobilization (Car Alarm I) with standard horn

Alarm switch 2 switches "positive" (+) to alarm relay 1, horn switch switches "positive".  
(Earlier circuit without relay 12).

In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.




1 = Alarm relay  
 2 = Alarm switch  
 4 = Ignition/starting  
 (driving) switch

6 = Ignition coil  
 11 = Starting motor  
 12 = Auxiliary relay (12 V,  
 change-over contact,  
 here as normally-  
 closed contact)

#### 4.1.7 Basic circuit with starting motor immobilization (Car Alarm I)


Alarm switch 2 switches "negative" (-) to alarm relay 1.  
 (Earlier circuit, now without relay (12).)



- |  |   |
|--|---|
| 1 = Alarm relay                        | 6 = Ignition coil   |
| 2 = Alarm switch                       | 11 = Starting motor   |
| 4 = Ignition/starting (driving) switch | 12 = Auxiliary relay (12 V, change-over contact, here as normally-closed contact) |
| 5 = Fuse box (8 A fuse)                |   |

#### 4.1.8 Basic circuit with starting motor immobilization (Car Alarm I)

Alarm switch 2 switches "positive" (+) to alarm relay 1 (earlier circuit without relay (12).)




1 = Alarm relay  
 2 = Alarm switch  
 4 = Ignition/starting  
 (driving) switch

6 = Ignition coil  
 11 = Starting motor

#### 4.1.9 New basic circuit with starting motor immobilization (Car Alarm I)

Alarm switch 2 switches "negative" (-) to alarm relay 1.

Can also be used for vehicles with electronic ignition system/Motronic.



- 1 = Alarm relay
- 2 = Alarm switch
- 4 = Ignition/starting (driving) switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 11 = Starting motor


#### 4.1.10 New basic circuit with starting motor immobilization (Car Alarm I)

Alarm switch 2 switches "positive" (+) to alarm relay 1.

Can also be used for vehicles with electronic ignition system/Motronic.








- 1 = Alarm relay
- 1a = Evaluation electronics
- 1c = Ultrasonic movement detector
- 2 = Alarm switch (push-pull switch)
- 3 = Alarm horn
- 4 = Ignition/starting (driving) switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 12 = Relay (12 V, change-over contact, here as normally-open contact)
- 19 = Door-contact switch
- 22 = Interior lamp

bl = blue  
gn = green  
rt = red

#### 4.1.12 Basic circuit-Car Alarm I with Car Alarm Plus 4 (ignition immobilization)

Alarm switch 2 switches "negative" to alarm relay. Door-contact switch switches negative. In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.






- |                                   |  |
|-----------------------------------|--|
| 1 = Alarm relay                   | 6 = Ignition coil  |
| 2a = Evaluation electronics       | 12 = Relay (12 V change-over contact, here as normally-open contact) |
| 1c = Ultrasonic movement detector |  |
| 2 = Alarm switch                  | 19 = Door-contact switch   |
| 3 = Alarm horn                    | 22 = Interior lamp   |
| 4 = Ignition/starting switch      | 34 = Relay (12 V, twin normally-open contact)                        |
| 5 = Fuse box (8 A fuse)           |  |
|                                   | bl = blue    rt = red  |
|                                   | gn = green   |

#### 4.1.13 Basic circuit-Car Alarm I with Car Alarm Plus 4 (ignition immobilization)


Alarm switch 2 switches "negative" to alarm relay. Door-contact switch switches "positive". In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.





- 1 = Alarm relay  
13 = heated rear window  
17 = to switch/relay for heated rear window


4.1.14 Auxiliary circuit for protecting the rear window  
through heating circuit for rear window, for  
Car Alarm I



1 = Alarm relay  
15 = Contact switch

#### 4.1.15 Auxiliary circuit for Car Alarm I

Protection of luggage compartment and engine hood by 2 contact switches (15).




- 1 = Alarm relay  
 3 = Alarm horn  
 16 = Auxiliary relay (12 V, twin normally-open contact)

#### 4.1.16 Auxiliary circuit for Car Alarm I

##### Auxiliary visual alarm via auxiliary relay (16)


Note:

Not allowed in the Federal Republic of Germany.



1 = Alarm relay  
7 = Car radio

4.1.17 Auxiliary circuit for Car Alarm I  
Protection of car radio




- 1 = Alarm relay  
 14 = Auxiliary lamp  
 16 = Auxiliary relay (12 V, twin normally-open contact)

#### 4.1.18 Auxiliary circuit for Car Alarm I Protection of auxiliary lamps

##### Note:

Not allowed in the Federal Republic of Germany.






- |  |   |
|--|---|
| 1 = Alarm relay                        | 8 = Battery   |
| 2 = Alarm switch                       | 9 = Thermo-switch/switching relay                                     |
| 4 = Ignition/starting (driving) switch | 10 = Radiator fan   |
| 5 = Fuse box (8 A fuse)                | 12 = Relay (12 V, change-over contact, here as normally-open contact) |
| 6 = Ignition coil                      |   |

#### 4.1.19 Special circuit for Car Alarm I

Prevention of alarm through startup of radiator fan (+switched) with vehicle parked

Alarm switch 2 switches "negative" to alarm relay 1. In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.






- |  |   |
|--|---|
| 1 = Alarm relay                        | 8 = Battery   |
| 2 = Alarm switch                       | 9 = Thermo-switch/switching relay                                     |
| 4 = Ignition/starting (driving) switch | 10 = Radiator fan   |
| 5 = Fuse box (8 A fuse)                | 12 = Relay (12 V, change-over contact, here as normally-open contact) |
| 6 = Ignition coil                      |   |

#### 4.1.21 Special circuit for Car Alarm I

##### Prevention of alarm through startup of radiator fan (-switched) with vehicle parked

In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.




- |  |   |
|--|---|
| 1 = Alarm relay                        | 8 = Battery   |
| 2 = Alarm switch                       | 9 = Thermo-switch/switching relay                                     |
| 4 = Ignition/starting (driving) switch | 10 = Radiator fan   |
| 5 = Fuse box (8 A fuse)                | 12 = Relay (12 V, change-over contact, here as normally-open contact) |
| 6 = Ignition coil                      |   |

#### 4.1.22 Special circuit for Car Alarm I

##### Prevention of alarm through startup of radiator fan

Alarm switch 2 switches "positive" to alarm relay 1. In order to prevent unintentional switching-off of the ignition while driving, an additional relay (12) can be installed.




- 1 = Alarm relay
- 2 = Alarm switch
- 9 = Thermo-switch/switching relay
- 10 = Radiator fan
- 12 = Auxiliary relay (12 V, change-over contact, here as normally-closed contact)
- 20 = Heating blower motor
- 21 = Thermostat switch for heating blower motor

#### 4.1.23 Special circuit for Car Alarm I

Prevention of alarm by auxiliary relay (12)

through startup of heating blower motor


(+switched) in conjunction with auxiliary heater with vehicle parked.



- |                                       |  |
|---------------------------------------|--|
| 1 = Alarm relay                       | 10 = Radiator fan                                  |
| 2 = Alarm switch                      | 20 = Heating blower motor                          |
| 9 = Thermo-switch/<br>switching relay | 21 = Thermostat switch for<br>heating blower motor |

#### 4.1.24 Special circuit for Car Alarm I

Prevention of alarm through startup of heating blower motor (-switched), in conjunction with auxiliary heater with vehicle parked.




- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 5 = Fuse box (8 A fuse)
- 12 = Relay (12 V, change-over contact, here as normally-open contact)
- 35 = Electric fuel pump relay
- 39 = Electric fuel pump

#### 4.1.25 Special circuit for Car Alarm I

##### Circuit for vehicles with Motornic

In order to prevent unintentional switching-off of the electric fuel pump relay while driving, an additional relay (12) can be installed.






- |                         |                           |
|-------------------------|---------------------------|
| 1 = Alarm relay         | 6 = Ignition coil         |
| 2 = Alarm switch        | 6a = Ignition distributor |
| 3 = Alarm horn          | 15 = Contact switch       |
| 4 = Ignition/starting   | (luggage compartment,     |
| (driving) switch        | engine hood)              |
| 5 = Fuse box (8 A fuse) | 19 = Door-contact switch  |
|                         | 22 = Interior lamp        |

## 4.2 Circuit diagrams - Car Alarm II

### 4.2.1 Basic circuit with ignition immobilization. Door-contact switch switches "negative" (Car Alarm II)

Does not apply to vehicles with electronic ignition systems or Motronic.






- 1 = Alarm relay
- 4 = Ignition/starting (driving) switch
- 11 = Starting motor
- 34 = Relay (12 V, change-over contact, here as normally-closed contact)

#### 4.2.2 Basic circuit with starting motor immobilization (Car Alarm II)

Can be used for vehicles with electronic ignition or Motronic.




1 = Alarm relay  
32 = Glow-plug monitor


31 = Glow-plug switch term.19  
32 = Glow plug

#### 4.2.3 Basic circuit - Glow plug immobilization (Car Alarm II)

For Diesel vehicles in conjunction with starting motor immobilization.



For Diesel vehicles in conjunction with starting immobilization. Lead 15 to the glow-duration unit is open-circuited by auxiliary relay.




335/048

1 = Alarm relay  
4 = Ignition/starting  
(driving) switch

23 = Charge indicator lamp  
24 = Alternator

#### 4.2.5 Basic circuit via alternator (Car Alarm II)

Triggering of alarm through running of alternator.




- 1 = Alarm relay
- 1a = Evaluation electronics trigger box
- 1b = Angle sensor
- 5 = Fuse box (8 A fuse)
- 15 = Contact switch
- 18 = Luggage compartment/engine compartment lamp

br = brown  
gn = green  
ws = white

#### 4.2.6 Basic circuit - Car Alarm II

with Car Alarm Plus 3 (wheel protection)






- |  |   |
|--|---|
| 1 = Alarm relay                        | 15 = Contact switch for engine hood/luggage compartment |
| 1a = Evaluation electronics            |   |
| 1c = Ultrasonic movement detector      |   |
| 2 = Alarm switch                       | 19 = Door contact                                       |
| 3 = Alarm horn                         | 22 = Interior lamp                                      |
| 4 = Ignition/starting (driving) switch |   |
| 5 = Fuse box (8 A fuse)                | bl = blue   |
| 6 = Ignition coil                      | gn = green  |
|  | rt = red  |

#### 4.2.7 Basic circuit - Car Alarm II with

##### Car Alarm Plus 4 (ignition immobilization)

Door contact switches negative. Circuit does not apply to vehicles with electronic ignition system or Motronic.





- |                              |   |
|------------------------------|---|
| 1 = Alarm relay              | 15 = Contact switch for engine hood/luggage compartment                 |
| 2 = Alarm switch             | 19 = Door contacts  |
| 3 = Alarm horn               | 22 = Interior lamp  |
| 4 = Ignition/starting switch | 34 = Relay (12 V, change-over contact, here as normally-closed contact) |
| 5 = Fuse box (8 A fuse)      |   |
| 8 = Vehicle batteries 24 V   |   |
| 11 = Starting motor          |   |


#### 4.2.8 Basic circuit with starting motor immobilization (Car Alarm II)

For vehicles with 24 V without separate alarm battery.  
Negative to ground.










1 = Alarm relay                      22 = Interior lamp  
 19 = Door contact switch

#### 4.2.10 Auxiliary circuit for Car Alarm II

Additional rear door contacts ("positive-switched").




1 = Alarm relay  
2 = Alarm switch

7 = Car radio

#### 4.2.11 Auxiliary circuit for Car Alarm II Protection of car radio.

Note:

Radio protection also functions with alarm system off.




- 1 = Alarm relay
- 5 = Fuse box (8 A fuse)
- 8a = Alarm battery 12 V (e.g. 0 180 051 612)
- 51 = Stop-lamp switch
- 52 = Tractor stop lamps
- 53 = Trailer stop lamps
- 54 = Relay (24 V, change-over contact, here as normally-closed contact)
- 55 = Relay (24 V, normally-open contact)

#### 4.2.12 Auxiliary circuit for Car Alarm II

Trailer protection for vehicles with 24 V and separate alarm battery.

Negative to ground.



1 = Alarm relay  
3 = Alarm horn


16 = Auxiliary relay  
(12 V, twin normally-open  
contact)

#### 4.2.13 Auxiliary circuit for Car Alarm II

Additional visual alarm via auxiliary relay (16).

Note:


Not allowed in the Federal Republic of Germany.



- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition/starting (driving) switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coils
- 8 = Battery
- 15 = Contact switches for engine hood/luggage compartment
- 16 = Relay (12 V, twin normally-open contact)
- 19 = Door contact switches
- 22 = Interior lamp

#### 4.2.14 Special circuit for Car Alarm II


Peugeot 604 with double contact breaker and Car Alarm II.



- 1 = Alarm relay
- 3a = Switch for standard horn
- 3b = Standard horn

#### 4.2.15 Special circuit for Car Alarm II

Circuit with standard horn, horn switch switches "negative".




- 1 = Alarm relay
- 3a = Switch for standard horn
- 3b = Standard horn
- 5 = Fuse box (8 A fuse)

#### 4.2.16 Special circuit for Car Alarm II

Circuit with standard horn, horn switch switches "positive".






- |  |                                      |
|--|--------------------------------------|
| 1 = Alarm relay                                      | 28 = Front interior lamp with switch |
| 19 = Door contact switch                             | 29 = Rear interior lamp              |
| 25 = Manually-operated switch for rear interior lamp | 37 = Time-delay relay                |
| 26 = Blocking diode                                  |                                      |

#### 4.2.17 Special circuit for Car Alarm II

Circuit for Mercedes Benz passenger cars with front and rear interior lamps.






- 1 = Alarm relay
- 34 = Auxiliary relay (12 V change-over contact, here as normally-closed contact)
- 39 = Electric fuel pump
- 57 = Relay set

#### 4.2.18 Special circuit for Car Alarm II


For vehicles with L-Jetronic, cutting off of electric fuel pump.



- 1 = Alarm relay
- 5 = Fuse box (8 A fuse)
- 34 = Auxiliary relay (12 V, change-over contact, here as normally-closed contact)
- 39 = Electric fuel pump
- 56 = L-Jetronic (version LE) control relay


#### 4.2.19 Special circuit for Car Alarm II

For vehicles with L-Jetronic (version LE), cutting off of electric fuel pump.



For vehicles with Motronic, cutting off of electric fuel pump.

Note: Since there are now also Motronic vehicles with twin relays, it is no longer the positive lead to the fuel pump, but lead 20 from Motronic control unit to fuel pump relay that is open-circuited in the case of alarm.



- 1 = Alarm relay
- 4 = Ignition and starting switch
- 6b = Trigger box TSZ-H/TZ-H, TSZ-I/TZ-I
- 26 = Damping diode (e.g. U 212 911 001)
- 34 = Additional relay (12 V change-over contact break-before-make, here normally-closed contact)


#### 4.2.21 Special circuitry for Car Alarm II (continued)

● Subsequently installed TSZ-H,  
when resistance cable already in vehicle between the ignition and starting switch and the ignition coil term. 15 has been replaced with a new cable (1.5 mm<sup>2</sup>).

#### Note:

The terminal designations of the damping diode (26) has been changed as of date of manufacture 832 (see illustration). The old designations are in parentheses.






- 335/66
- 1 = Alarm relay
  - 4 = Ignition/starting switch
  - 5 = Fuse box (8 A fuse)
  - 6 = Ignition coil
  - 6b = Trigger box (TSZ-H/TZ-H, TSZ-I/TZ-I)
  - 12 = Relay (12 V, change-over contact, here as normally-open contact)
  - 26 = Protective diode (e.g. 0 212 911 001)
  - 34 = Auxiliary relay (12 V, change-over contact, here as normally-closed contact)
  - 38 = Resistance cable (in vehicle wiring harness)

#### 4.2.22 Special circuit for Car Alarm II

For vehicles with:

- Subsequently installed TSZ-H, TZ-H, where the resistance cable (38) in the vehicle was left in place and a relay (12) is installed for controlling the positive current to TSZ/TZ trigger box (6b) and ignition coil (6).




- 1 = Alarm relay
- 5 = Ignition/starting switch
- 5 = Fuse box (8 A fuse)
- 6 = Ignition coil
- 6b = Trigger box (TSZ-H/TZ-H, TSZ-I/TZ-I)
- 12 = Relay (12 V, change-over contact, here as normally-open contact)
- 26 = Protective diode (e.g. 0 212 911 001)
- 34 = Auxiliary relay (12 V, change-over contact, here as normally-closed contact)
- 38 = Resistance cable (in vehicle wiring harness)

### Special circuit for Car Alarm II (continued)

#### Note:

As of date of manufacture 832, the terminal designations on the protective diode (26) have been changed (see picture). Old designations in parentheses.





rt = red  
br = brown

gr = gray  
sw = black

gn = green  
ge = yellow

a = leads are not connected.


1 = Alarm relay  
1d = Sensor

6 = Ignition coil  
12 = Relay (12 V, change-over contact, here as normally-closed contact)

### 4.3 Circuit diagrams - Two-wheeled vehicle alarm

#### 4.3.1 Basic circuit with ignition immobilization for vehicle without battery

"Positive" lead (59) to ignition coil is open-circuited by auxiliary relay.



1 = Alarm relay

1d = Sensor

3a = Switch for standard  
horn  
Fuse (8 A)

3b = Standard horn

5 = Fuse (8 A)

8 = Battery

rt = red

br = brown

gr = gray


sw = black

#### 4.3.2 Basic circuit with standard horn (two-wheeled vehicle alarm)

Horn switch switches "positive"

Caution: Fasten brown lead not directly on battery -,  
but on vehicle frame.





1 = Alarm relay

1d = Sensor

3a = Switch for standard horn  
Fuse (8A)

3b = Standard horn

5 = Fuse (8 A)

8 = Battery

rt = red

br = brown


gr = gray

sw = black

#### 4.3.3 Basic circuit with standard horn (two-wheeled vehicle alarm)

Horn switch switches "negative"

Caution: Do not fasten brown and gray leads directly to battery -, but to vehicle frame.



- |                               |   |
|-------------------------------|---|
| 1 = Alarm relay               | 4a = RUN-OFF switch   |
| 1d = Sensor                   | 5 = Fuse (8 A)  |
| 3a = Switch for standard horn | 6 = Ignition coil   |
| 3b = Standard horn            | 8 = Battery   |
|                               | 12 = Relay (12 V, change-over contact, here as normally-closed contact) |


br = brown	gr = gray
ge = yellow	rt = red
gn = green	sw = black

#### 4.3.4 Basic circuit with ignition immobilization (two-wheeled vehicle alarm)

Horn switch switches "positive", lead 15 to ignition coil is open-circuited by auxiliary relay.

Note: Do not fasten brown lead directly on battery -, but on vehicle frame.





335/73

1 = Alarm relay

1a = Sensor

3a = Switch for standard horn

3b = Standard horn

4a = RUN-OFF switch

5 = Fuse (8 A)

6 = Ignition coil

8 = Battery

12 = Relay (12 V,  
change-over contact  
here as normally-  
closed contact)

br = brown

ge = yellow

gn = green

gr = gray


rt = red

sw = black

#### 4.3.5 Basic circuit with ignition immobilization (two-wheeled vehicle alarm)

Horn switch switches "negative". Lead 15 to ignition coil is open-circuited by auxiliary relay.

Note: Do not fasten brown and gray leads directly on battery -, but on vehicle frame.




1 = Alarm relay  
1d = Sensor

14 = Auxiliary lamp  
60 = Helmet

#### 4.3.6 Auxiliary circuit for two-wheeled vehicle alarm

Protection of helmet and auxiliary lamp.



- |                        |                            |
|------------------------|----------------------------|
| 1 = Alarm              | 34 = Start-interrupt relay |
| 2 = Alarm switch       | (12 V change-over          |
| 3 = Alarm horn         | contact break-before       |
| 4 = Ignition and       | make, here normally-       |
| starting switch        | closed contact)            |
| 5 = Fuse box           | 62 = Battery main switch   |
| (8 A fuse)             | 63 = Boat compass          |
| 8 = on-board battery   | 64 = Depth sounder         |
| 11 = Starter           | 65 = Radio                 |
| 15 = Contact switches, |                            |
| e.g. at cabin doors,   |                            |
| engine and stowage     |                            |
| room hatches, etc.     |                            |

#### 4.4 Circuit diagram for Boat Alarm system



## 5. Trouble-shooting

The trouble-shooting procedure is divided into

- Test conditions
- General trouble-shooting
- Trouble-shooting chart (customer complaint)
- Trouble-shooting program (detailed trouble-shooting)

### 5.1 Test conditions

Check the customer complaint / triggering of alarm.

Switch on (arm) the anti-theft alarm system.

Open and close all doors one after the other.

Open and close engine hood and luggage-compartment lid.

Operate starting motor.

Alarm must sound immediately or after approx. 5 seconds, depending on system.

With Car Alarm Plus 3, also raise vehicle with jack (wheels must not be clear) until alarm sounds.

With Car Alarm Plus 4, disturb 3-dimensional ultrasonic field in passenger compartment by opening door, reaching in through window etc. Alarm must sound immediately or after approx. 5 seconds, depending on system.

With two-wheeled vehicle alarm, raise parking stand. Alarm must sound immediately.

Open-circuiting of ignition need not be connected.



With the Boat Alarm, wait for a priming period of 20 seconds. Open and close hatches which are to be secured, such as cabin, engine compartment, stowage compartments ..

Activate starting motor.

The alarm will sound approx. 5 sec. after the cabin door is opened.

The alarm must sound immediately when the engine or storage compartment is opened, or when accessories such as radio, depth sounder, or compass are removed.

When ignition is switched on, the alarm should sound immediately, with the starting motor being blocked.

If one of these actions fails to initiate an alarm, or if it is possible to start the engine, the alarm system is defective.



## 5.2 General trouble-shooting

Car alarm systems, two-wheeled vehicle alarm systems or boat alarm systems are switched off (deprimed). Check the entire systems circuitry for proper connection and good contact, eliminating any defects.

Disconnect the alarm horn connected to the alarm system and connect directly to B + and ground for testing. Replace alarm horn, if defective.

Voltage test with Car Alarm I at terminal 30b of alarm relay (not in case of negative-switched systems). Voltage should be = battery voltage

Voltage test with Car Alarm II at terminal 30 of alarm relay (not in case of negative-switched systems) voltage should be = battery voltage

Voltage test with two-wheeled vehicle alarm at red or brown lead of alarm relay wiring harness voltage should be = battery voltage

Voltage test for Boat Alarm at alarm relay term. 30  
Nominal voltage: battery voltage





### With Car Alarm II only

Alarm switch not connected.

Voltage test at alarm relay between terminal E and vehicle ground.

Voltage should be  $\geq 12$  V  
otherwise alarm relay defective.

Alarm switch connected and on. Voltage test at alarm switch at lead coming from terminal E of alarm relay.  
Voltage should be = 3.5... 4.5 V

Alarm switch connected, but off. Voltage test at alarm switch at lead coming from terminal E of alarm relay.  
Voltage should be = 5.5 ... 6.5 V

### 24 V systems (Car Alarm II only)

In vehicles with battery main switch, the vehicle battery must not be disconnected since otherwise protection of the trailer is not guaranteed.

When, with the alarm system on, the vehicle battery is disconnected, the alarm sounds.

### Two-wheeled vehicle alarm

When, with the alarm system on, the vehicle battery is disconnected, the alarm sounds immediately via the built-in buzzer since alarm relay is supplied internally from 9 V battery.



### Special note

If the car radio is also protected against theft, the ground lead of the alarm switch is routed to ground via the car radio.

If the car radio is removed, the free lead from the alarm switch must be grounded.

For simultaneous accessory-theft protection in the Boat Alarm, a ground cable is looped from term. R1 to the alarm relay via the consuming devices.

If one of the inputs R1, R2, or R3 on the alarm relay in the boat alarm is not assigned, this input must not be connected to ground for testing.

When removing the car radio, the freed cable leading to the alarm switch must be connected to ground.



### 5.3 Trouble-shooting chart

Customer complaint (fault symptoms)


The fault symptoms listed below may be due to one or more faults.

1. False alarm with Car Alarm I, II, two-wheeled vehicle alarm, after installation with system armed.
2. False alarm with Car Alarm I, II, two-wheeled vehicle alarm, after the system has worked correctly for some time.
3. No alarm with Car Alarm I, alarm switch on.

			Cause of trouble	Coordinates
●			Incorrect wiring when installing the system. Door contacts must not be connected to terminal S and R. (No additional contacts for two-wheeled vehicle alarm).	D 19
●			Contact switches of hood and luggage-compartment lid are not connected to terminal S. (No additional contacts for two-wheeled vehicle)	D 19
●	●		Positive- or negative-switched fan motor incorrectly wired. Not with 2-wheeled vehicle alarm	D 21
	●	●	Loose contact in ground lead of an electrical device which is routed via terminal R of alarm relay.	E 1
	●	●	Short circuit/short circuit to ground between leads.	E 1
●			Sensor incorrectly connected, lead pointing downward. Only in case of two-wheeled vehicle.	E 15
●			Vehicle battery not connected. Two-wheeled vehicle only.	E 15
	●		Loose contact in sensor lead. Two-wheeled vehicle only.	E 15

**D6**

Trouble-shooting  
Alarm systems



**D7**

Trouble-shooting  
Alarm systems



# Trouble-shooting chart (continued)

Customer complaint (fault symptoms)

The fault symptoms listed below may be due to one or more faults.

3. No alarm with Car Alarm I, alarm switch on.

4. False alarm with Car Alarm II, alarm switch off.

5. False alarm with Car Alarm II, alarm switch on.

			<u>Cause of trouble</u>	<u>Coordinates</u>
●			Interior lamp not lit: switch, leads, fuse defective.	E 3
●			Interior lamp lit: open circuit in power supply to alarm relay, alarm relay, <u>alarm</u> switch or alarm horn defective	E 3
●			If engine compartment or luggage compartment lighting O.K., fault at alarm relay or lead.	E 3
●		●	Short circuit or short circuit to ground in switch or lead to switched-on device	E 5
		●	Short circuit in alarm relay between terminals A and B	E 7


**D8**

Trouble-shooting  
Alarm systems



**D9**

Trouble-shooting  
Alarm systems



# Trouble-shooting chart (continued)

Customer complaint (fault symptoms)

The fault symptoms listed below may be due to one or more faults.

4. False alarm with Car Alarm II. Alarm switch off.

5. False alarm with Car Alarm II. Alarm switch on.

6. No triggering of alarm with Car Alarm II. Alarm switch on.

<u>Cause of trouble</u>			<u>Coordinates</u>
●	●	Alarm switch defective: Internal resistance 0 $\Omega$ or connector dropped off.	E 7
●	●	Moisture in alarm switch	E 7
●	●	Open circuit in ground connection of alarm switch	E 7
	●	Corresponding lamp not lit: Switch, lead or fuse defective.	E 9
	●	Corresponding lamp lit: Open circuit in leads to connections of alarm relay S - T + or T -. Connector loose etc., alarm horn or relay defective.	E 9
	●	Open circuit in lead to terminal S +.	E 9
	●	Radio ground lead via alarm switch to terminal E dropped off.	E 9
	●	Alarm relay defective.	E 9

**D 10**

Trouble-shooting  
Alarm systems



**D 11**

Trouble-shooting  
Alarm systems



# Trouble-shooting chart (continued)

Customer complaint (fault symptoms)

The fault symptoms listed below may be due to one or more faults.

7. No alarm with Car Alarms I and II with additional Car Alarm Plus 3 (wheel protection). Alarm switch on.
8. No alarm with Car Alarms I and II with additional Car Alarm Plus 4 (passenger-compartment protection). Alarm switch on.
9. No alarm with two-wheeled vehicle alarm. Alarm switch on.
10. False alarm with two-wheeled vehicle alarm. Alarm switch off.

<u>Cause of trouble</u>				<u>Coordinates</u>
●			Plug-in connections on alarm relay or angle sensor dropped off.	E 11
●	●		Evaluation electronics defective.	E 13
	●		Evaluation electronics or ultrasonic detector defective.	E 13
●			Angle sensor defective.	E 11
		●	Alarm relay defective.	E 15
		●	No voltage at red lead No ground connection at brown lead	E 15
		●	flat battery in alarm relay	E 15
		●	Sensor defective.	E 15

**D 12**

Trouble-shooting  
Alarm systems



**D 13**

Trouble-shooting  
Alarm systems



# Trouble-shooting chart (continued)

Customer complaint (symptoms of trouble)

The symptoms of trouble listed below can have one or more causes.

- 11. False alarm with Boat Alarm after installation when system is primed
- 12. False alarm with Boat Alarm after system has been operating satisfactorily for a time
- 13. No alarm with Boat Alarm, alarm switched on

			<u>Cause of trouble</u>	<u>Coordinates</u>
•			Incorrect connection during installation of system.	E 19
	•	•	Defective alarm switch.	E 21, F 1
	•	•	Short circuit or ground connection between leads.	E 21, E 23
		•	No battery voltage at alarm relay.	-
	•	•	Defective alarm relay.	E 21, E 23
•	•		Circuit break in contact switches.	E 19, E 23, F 3
		•	Defective fuse.	E 23
		•	Defective alarm horn or open circuit in lead to horn	-

**D 14**

Trouble-shooting  
Alarm systems



**D 15**

Trouble-shooting  
Alarm systems



# Trouble-shooting chart (continued)

Customer complaint (symptoms of trouble)

The symptoms of trouble listed below can have one or more causes.

14. False alarm with Boat Alarm, alarm switched off.

15. False alarm with Boat Alarm, alarm switched on.

16. Engine starting possible despite "armed" system.

<u>Cause of trouble</u>				<u>Coordinates</u>
•			Defective alarm switch.	F 1
•	•		Alarm relay.	F 1, F 3
	•		Circuit break in contact switches.	F 3
		•	Defective fuse	E 23
		•	Defective start-interrupt relay.	E 23
		•	No battery voltage at alarm relay.	-

**D16**

Trouble-shooting

Alarm systems



**D17**

Trouble-shooting

Alarm systems





## 5.4 Trouble-shooting program

### Aim of trouble-shooting program

This program is intended to assist workshop employees to rapidly diagnose causes of trouble in vehicle or boat alarm systems, using the proper test equipment.

### Test procedure

The test steps on the left in the trouble-shooting program contain test instructions.

If a fault is found during a test step, proceed according to the repair instructions given in the box on the right.



## 5.5 Car Alarm I


### 5.5.1 False alarm with Car Alarm I - immediately after installation - alarm switch on

When door is opened, alarm  
sounds immediately

Incorrect wiring when installing system or alarm  
relay defective. Door contacts must not be connected  
to terminals "S" and "R". Change connections.

When luggage-compartment lid  
and hood are opened, alarm  
sounds with a delay of a few  
seconds

Incorrect wiring when installing the system.  
Contact switches for hood and luggage-compartment  
lid are not connected to terminal "S".  
Make connection.  
Use contact switches.



1 = Alarm relay  
15 = Contact switches  
(e.g. for hood and luggage  
compartment)



### 5.5.2 False alarm with Car Alarm I after stopping the engine when hot, alarm switch on.

Alarm sounds immediately when fan motor cuts in through thermostat

Incorrect wiring when installing system.  
Caution: + and - switched fan motors.  
Connect according to circuit diagram.

#### Top diagram:

Prevention of alarm through startup of radiator fan (+switched) with vehicle parked.

Alarm switch 2 switches "negative" (-) to alarm relay 1.

To prevent unintentional switching off of the ignition while driving, an additional relay (12) can be installed.

#### Center diagram:

Prevention of alarm through startup of radiator fan (+switched) with vehicle parked.

Alarm switch 2 switches "positive" (+) to alarm relay 1.

To prevent unintentional switching off of the ignition while driving, an additional relay (12) can be installed.

#### Bottom diagram:

Prevention of alarm through startup of radiator fan (-switched) with vehicle parked.

Alarm switch 2 switches "negative" (-) to alarm relay 1.

To prevent unintentional switching off of the ignition while driving, an additional relay (12) can be installed.

#### Key to diagrams:

1 = Alarm relay

2 = Alarm switch

4 = Ignition/starting switch

5 = Fuse box

(8 A fuse)

6 = Ignition coil





8 = Battery

9 = Thermo-switch

10 = Radiator fan

12 = Relay

(12 V, change-over contact, here as normally-open contact)



False alarm with Car Alarm I after stopping the engine when hot,  
alarm switch on (continued)

Top diagram:

Prevention of alarm through startup of radiator fan (-switched) with vehicle parked. Alarm switch switches "positive" (+) to alarm relay 1. To prevent unintentional switching off of the ignition while driving, an additional relay (12) can be installed.

5.5.3 False alarm with Car Alarm I after switching on of auxiliary  
heater, alarm switch on

Alarm sounds immediately  
after switching on of  
auxiliary heater (through  
timeswitch)

Incorrect wiring when installing system.  
Caution: + and -switched fan motors.  
Connect according to circuit diagram.




Center diagram:

Prevention of alarm by relay (12) through startup of heater blower motor (20) (+switched) in conjunction with auxiliary heater with vehicle parked.

Bottom diagram:

Prevention of alarm by relay (12) through startup of heater blower motor (20) (-switched) in conjunction with auxiliary heater with vehicle parked.

- |                              |                   |   |  |
|------------------------------|-------------------|---|--|
| 1 = Alarm relay              | 5 = Fuse box      | 8 = Battery   | 20 = Heater blower motor                       |
| 2 = Alarm switch             | (8 A fuse)        | 9 = Thermo-switch   | 21 = Thermostat switch for heater blower motor |
| 4 = Ignition/starting switch | 6 = Ignition coil | 10 = Radiator fan   |  |
|                              |                   | 12 = Relay (12 V, change-over contact, here as normally-open contact) |  |



#### 5.5.4 False alarm with Car Alarm I after the system has already worked correctly for some time, alarm switch on




Alarm sounds immediately without detectable switching on of an electrical device

Loose contact in ground lead of an electrical device routed via terminal R of alarm relay (see diagrams for examples). Short circuit/short circuit to ground between leads (e.g. under foot mats at leadthroughs through metal walls etc.) the effects of which are not immediately noticeable. Check leads.

False alarm without arming is not possible (for this, terminals 53 and 53a in the alarm switch and terminals A and B in the alarm relay would have to be short-circuited simultaneously; in this case, there would be a continuous sounding of the alarm).

#### Key to diagrams

- 1 = Alarm relay
- 7 = Radio
- 13 = heated rear window
- 14 = Auxiliary lamp
- 16 = Auxiliary relay (twin normally-open contact)
- 17 = To switch/relay for heated rear window



E1

Trouble-shooting  
Alarm systems




E2

Trouble-shooting  
Alarm systems



### 5.5.5 No alarm with Car Alarm I - Alarm switch on



**E3**

Trouble-shooting  
Alarm systems



**E4**

Trouble-shooting  
Alarm systems



## 5.6 Car Alarm II

### 5.6.1 False alarm with Car Alarm II - Alarm switch on

Alarm without detectable switching on of an electrical device


Alarm switch defective:  
Internal resistance 0  $\Omega$  or connector dropped off alarm switch.  
Short circuit or moisture short circuit in alarm switch, due to heavy rain or water jet in car wash etc.  
Open circuit in ground connection of alarm switch due to: e.g. poor contact on vehicle body/engine, or at electrical devices (e.g. radio) whose ground lead is routed via alarm switch for protection.

Remedy fault.

Alarm when detectable switching on of an electrical device

Short circuit or short circuit to ground in switch or lead to the energized device.

Remedy fault.



1 = Alarm relay  
2 = Alarm switch  
7 = Radio



### 5.6.2 False alarm with Car Alarm II - Alarm switch off


Alarm with vehicle stopped or while driving

Alarm switch defective:  
Internal resistance 0  $\Omega$  or connector  
dropped off alarm switch.  
  
Short circuit or moisture short circuit  
in alarm switch, due to heavy rain or  
water jet in car wash etc.  
  
Open circuit in ground connection of alarm  
switch due to: e.g. poor contact on vehicle  
body/engine, or at electrical devices  
(e.g. radio) whose ground lead is routed  
via alarm switch for protection.

Remedy fault.

Alarm horn sounds  
continuously

Short circuit in alarm relay between  
terminals A and B - replace.



1 = Alarm relay  
2 = Alarm switch  
7 = Radio


**E7**

Trouble-shooting  
Alarm systems





**E8**

Trouble-shooting  
Alarm systems





### 5.6.3 No triggering of alarm with Car Alarm II - Alarm switch on



1 = Alarm relay  
2 = Alarm switch  
7 = Radio


E9

Trouble-shooting  
Alarm systems



E10



Trouble-shooting  
Alarm systems



## 5.7 Car Alarm Plus 3 (wheel protection)

### 5.7.1 No alarm with Car Alarm Plus 3 (wheel protection) - Alarm switch on

Conditions: Car Alarm I or II O.K. (check as described previously; to do this, disconnect 6-pin plug from trigger box (evaluation electronics)).





Angle sensor



## 5.8 Car Alarm Plus 4 (passenger-compartment protection)

### 5.8.1 No alarm with Car Alarm Plus 4 (passenger-compartment protection), alarm switch on

Test conditions: Car Alarm I or II O.K.





Ultrasonic movement detector

Testing of Car Alarm I, II, Plus 3, Plus 4 completed.




## 5.9 Two-wheeled vehicle alarm

### 5.9.1 No alarm with two-wheeled vehicle alarm. Alarm switch on




1d = Sensor  
61 = Motorcycle stand

br=brown  
ge=yellow  
gn=green  
1 =Alarm relay  
gr=gray  
rt=red  
sw=black




**E15**

Trouble-shooting  
Alarm systems



**E16**


Trouble-shooting  
Alarm systems



If accessories are protected, such as helmet, saddle bag, auxiliary lamp etc., disconnect black lead from alarm relay. Alarm must sound immediately.

no

Alarm relay defective.  
After replacing alarm relay, carry out functional test.



sw = black  
1 = Alarm relay  
1d = Sensor  
14 = Auxiliary lamp  
60 = Helmet


**E17**

Trouble-shooting  
Alarm systems



**E18**

Trouble-shooting  
Alarm systems



## 5.10 Boat Alarm


### 5.10.1 False alarm with Boat Alarm immediately after installation when system is primed

Immediate alarm upon opening cabin door

Incorrect connection during installation of system, or defective alarm relay. Cabin-door contact may not be connected to term. R1 or R2. Alter connection.

Alarm delayed by a few seconds after opening engine or storage compartment hatch

Incorrect connection during installation of system. The contact switches for the engine and storage compartments are not connected to R 1 or R 2. Correct connections. Use original contact switches.



- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition and starting switch
- 5 = Fuse box (8A fuse)
- 8 = On-board battery
- 11 = Starting motor
- 15 = Contact switches e.g. at cabin doors, engine and storage compartment hatches, etc.
- 24 = Start-interrupt relay (12 V change-over contact break-before-make, here normally-closed contact)
- 62 = Battery master switch
- 63 = Boat compass
- 64 = Depth sounder
- 65 = Radio

**E19**

Trouble-shooting  
Alarm systems



**E20**

Trouble-shooting  
Alarm systems




5.10.2 False alarm with Boat Alarm after system has been operating satisfactorily for a time, alarm switched on

Immediate alarm without discernible opening of cabin or engine/storage compartment hatches.

Loose contact in accessory ground cable leading to term. R1 of the alarm relay, or in the lead from the contact switch at the engine/storage compartment to term. R2 on the alarm relay.

Check leads for short circuit or ground connection between the leads (e.g. where passing through metal walls etc.).



False alarm without priming is impossible (before this could happen, there would have to be a short circuit in the alarm switch and at the same time a connection between terminals B and 30b of the alarm relay; this would cause a continuous tone).




- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition and starting switch
- 5 = Fuse box  
(8A fuse)
- 8 = On-board battery
- 11 = Starting motor
- 15 = Contact switches e.g.  
at cabin doors, engine and  
storage compartment hatches, etc.
- 24 = Start-interrupt relay (12 V  
change-over contact break-before-  
make, here normally-closed  
contact)
- 62 = Battery master switch
- 63 = Boat compass
- 64 = Depth sounder
- 65 = Radio



5.10.3 No alarm with Boat Alarm - alarm switch on



- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition and starting switch
- 5 = Fuse box  
(8A fuse)
- 8 = On-board battery
- 11 = Starting motor
- 15 = Contact switches e.g.  
at cabin doors, engine and  
storage compartment hatches, etc.
- 24 = Start-interrupt relay (12 V  
change-over contact break-before-  
make, here normally-closed  
contact)
- 62 = Battery master switch
- 63 = Boat compass
- 64 = Depth sounder
- 65 = Radio






#### 5.10.4 False alarm with Boat Alarm, alarm switched off

Alarm when boat is turned off or underway

Alarm switch defective:  
Internal resistance 0  $\Omega$ .  
Switch has closing contact, with simultaneous short circuit or short caused by moisture in alarm relay.

Alarm horn produces continuous tone.

Alarm relay has short circuit between terms. 31b and B; replace alarm relay.



- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition and starting switch
- 5 = Fuse box  
(8A fuse)
- 8 = On-board battery
- 11 = Starting motor
- 15 = Contact switches e.g.  
at cabin doors, engine and  
storage compartment hatches, etc.
- 24 = Start-interrupt relay (12 V  
change-over contact break-before-  
make, here normally-closed  
contact)
- 62 = Battery master switch
- 63 = Boat compass
- 64 = Depth sounder
- 65 = Radio

F1

Trouble-shooting  
Alarm systems



F2

Trouble-shooting  
Alarm systems



#### 5.10.5 False alarm with Boat Alarm-Alarm switched on


Alarm without discernible opening of a hatch or removal of an accessory.

Alarm switch defective:  
Internal resistance 0  $\Omega$  or plug has fallen out of alarm switch.

Contact switch defective, open Reed contacts.

Defective contact switch at terminals R1, R2, or R3

Rectify faults.



- 1 = Alarm relay
- 2 = Alarm switch
- 3 = Alarm horn
- 4 = Ignition and starting switch
- 5 = Fuse box  
(8A fuse)
- 8 = On-board battery
- 11 = Starting motor
- 15 = Contact switches e.g.  
at cabin doors, engine and  
storage compartment hatches, etc.
- 24 = Start-interrupt relay (12 V  
change-over contact break-before-  
make, here normally-closed  
contact)
- 62 = Battery master switch
- 63 = Boat compass
- 64 = Depth sounder
- 65 = Radio

# After-sales Service

## Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

13...39

CAR ALARM PLUS 4 (ULTRASONIC)

VDT-I-335/112 En

0 986 335 003

7. 1983

### General information

#### Operating principle:

Ultrasound is mechanical vibrations above the frequency range of the human ear. The sensor generates ultrasonic waves which are subject to lobar propagation and thus scan the interior of the vehicle, building up an ultrasonic field. As soon as the ultrasonic field undergoes a change this is evaluated by the receiver and the alarm is triggered. Ultrasonic waves do not pass through walls or glass and are thus confined to the interior.

#### Application:

Optimum effect is achieved in passenger car interiors. In larger spaces (station wagon, motor home) there is such a drop in sensitivity that complete protection of the interior is no longer guaranteed. It is not possible to equip a larger space with two sensors in order to improve sensitivity. The sensors interfere with each other and trigger a false alarm. Two separate compartments can each be equipped with an ultrasonic system by using a basic system (car alarm 1 or car alarm 2).

#### Installation:

Smooth, hard surfaces such as windows, doors, leather covers reflect ultrasonic waves. The sensitivity is not thereby adversely affected.

Fabrics, plush, velvet, curtains absorb ultrasonic waves. This reduces the sensitivity.

Temperature fluctuations/direct sunlight do not lead to a false alarm.

**BOSCH**

Geschäftsbereich KH: Kundendienst, Kfz-Ausstattung  
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany  
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

**N1**

Technical Bulletin

Alarm systems



Optimum effect of the sensor is obtained if the installation location is as high as possible so that the ultrasonic waves can radiate freely.

After the system has been installed the sensitivity can be set at the alarm relay of the Plus 4 system.

See the installation instructions for further details.

Current consumption:

Car alarm Plus 4 in conjunction with car alarm 1 or 2: approx. 21 mA.

Please direct questions and comments concerning the contents to our authorized representative in your country.

**N2**

Technical Bulletin

Alarm systems



## TABLE OF CONTENTS

### Section      Coordinates

Structure of the microcard .....	A 1
1. Special features .....	A 2
2. Test specifications .....	A 3
3. Required testing equipment and tools ..	A 5
4. Possible circuit diagrams for Car Alarm I, II, Plus 3, Plus 4, Two- Wheeled Vehicle Alarm, Boat Alarm .....	A 6

#### Basic circuitry for Car Alarm I

4.1.1	Ignition block with separate alarm horn .....	A 7
4.1.2	Ignition block with standard and separate horn .....	A 8 - A 12
4.1.7	Starting-motor block .....	A 13 - A 16
4.1.11	Car Alarm I with Car Alarm <u>Plus 3</u> wheel protection system .....	A 17
4.1.12	Car Alarm I with Car Alarm <u>Plus 4</u> , ignition block .....	A 18 - A 19

#### Additional circuitry for Car Alarm I

4.1.14	Rear-window protection .....	A 20
4.1.15	Trunk and hood protection .....	A 21
4.1.16	Additional optical alarm .....	A 22
4.1.17	Car-radio protection .....	A 23
4.1.18	Auxiliary-headlamp protection .....	A 24



## Table of contents (continued)

### Section

### Coordinates

#### Special circuitry with Car Alarm I

- 4.1.19 Alarm prevention through  
radiator fan start ..... B 1 - B 4
- 4.1.23 Alarm prevention through heater  
blower start ..... B 5 - B 6
- 4.1.25 For vehicles with Motronic .... B 7

#### Basic circuitry for Car Alarm II

- 4.2.1 Ignition block ..... B 8
- 4.2.2 Starting-motor block ..... B 9
- 4.2.3 Glow-plug block with starting-  
motor block (diesel  
vehicles) ..... B 10
- 4.2.4 Glow-plug block with glow-  
duration unit ..... B 11
- 4.2.5 Alarm actuation via generator.. B 12
- 4.2.6 Car Alarm II with Car Alarm  
Plus 3 (wheel protection  
system) ..... B 13
- 4.2.7 Car Alarm II with Car Alarm  
Plus 4 ..... B 14
- 4.2.8 Starting-motor block for  
vehicles with 24 V ..... B 15
- 4.2.9 Starting-motor block for  
vehicles with 24 V and  
additional alarm battery ..... B 16

#### Additional circuitry for Car Alarm II

- 4.2.10 Rear door contact ..... B 17
- 4.2.11 Car-radio protection ..... B 18
- 4.2.12 Trailer protection for 24 V ... B 19
- 4.2.13 Optical alarm ..... B 20



## Table of contents (continued)

### Section

### Coordinates

#### Special circuitry for Car Alarm II

4.2.14	Peugeot 604 with double contact breaker .....	B 21
4.2.15	Standard-equipment horn .....	B 22 - B 23
4.2.17	Mercedes-Benz passenger vehicles with front and rear interior lamps .....	B 24
4.2.18	L-Jetronic, electric fuel pump switch-off .....	C 1
4.2.19	L-Jetronic (LE version), electric fuel pump switch-off ..	C 2
4.2.20	Motronic, electric fuel pump switch-off .....	C 3 - C 4
4.2.22	Subsequently installed TSZ-H, TZ-H .....	C 5 - C 6

#### Basic circuitry for Two-Wheeled Vehicle Alarm

4.3.1	Ignition block for vehicles without battery .....	C 7
4.3.2	With standard-equipment horn ..	C 8 - C 9
4.3.4	Ignition block for vehicles with battery .....	C 10 - C 11
4.3.6	Helmet and auxiliary headlamp protection .....	C 12

#### Basic circuitry for Boat Alarm

4.4	Boat Alarm system with start interrupt and accessory protection	
-----	---	--



## Table of contents (continued)

<u>Section</u>	<u>Coordinates</u>
5. Trouble-shooting .....	D 1
5.1 Requirements for testing ..	D 1
5.2 General trouble-shooting ..	D 3
5.3 Trouble-shooting chart ....	D 6
5.4 Trouble-shooting program ..	D 18
5.5 Car Alarm I .....	D 19
5.5.1 False alarm immediately after installation .....	D 19
5.5.2 False alarm after switching off engine at operating temperature .....	D 21
5.5.3 False alarm after switching on auxiliary heating .....	D 23
5.5.4 False alarm after system has been operating satisfactorily for a time .	E 1
5.5.5 No alarm with Car Alarm I .	E 3
5.6 Car Alarm II .....	E 5
5.6.1 False alarm with Car Alarm II .....	E 5
5.6.2 False Alarm with Car Alarm II .....	E 7
5.6.3 No alarm actuation with Car Alarm II .....	E 9
5.7 Car Alarm Plus 3 .....	E 11
5.7.1 No alarm with Car Alarm Plus 3 (wheel protection sytem) .....	E 11
5.8 Car Alarm Plus 4 .....	E 13
5.8.1 No alarm with Car Alarm Plus 4 (interior protection) .....	E 13
5.9 Two-Wheeled Vehicle Alarm .	E 15
5.9.1 No alarm with Two-Wheeled Vehicle Alarm, alarm switched on .....	E 15
5.10 Boat Alarm .....	E 19
5.10.1 False alarm immediatley after installation, alarm switched on .....	E 19





## Table of contents (continued)

<u>Section</u>	<u>Coordinates</u>
5.10.2 False alarm after the system has been working satisfactorily for a time, alarm switched on .....	E21
5.10.3 No alarm - alarm switched on .....	E23
5.10.4 False alarm, alarm switched off .....	F 1
5.10.5 False alarm, alarm switched on .....	F 3
Technical Bulletin	N 1

© 1986 Robert Bosch GmbH Automotive Equipment -  
After-Sales Service, Department for Technical  
Publications KH/VDT, Postfach 50, D-7000 Stuttgart 1.

Published by: After-Sales Service Department for  
Training and Technology (KH/VSK). Press date: 1.1986

Please direct questions and comments concerning the  
contents to our authorized representative in your  
country.

This publication is intended solely for the use of the  
Bosch After-Sales Service Organization, and may not be  
passed on to third parties without our consent.

Microfilmed in the Federal Republic of Germany.  
Microphotographié en République Fédérale d'Allemagne.

